

## MAGNETOFLEX® MAGNETIC SIGN INFORMATION SHEET

**In order to ensure a long service life of your new magnetic sign and to avoid potential damages, please read the following information carefully.**

### MOUNTING INSTRUCTIONS

- The surface must be completely dry, clean and free of dust.
- Hold the magnetic sign above the intended area and then lower it; do not slide it around (sliding may cause scratches).
- Do not position the sign over trims or sharp edges.
- Do not attach the magnetic sign onto freshly painted or polished surfaces; let the paint harden thoroughly.

**Note:** When correctly applied, the magnetic sign sticks to the car's body for speeds of up to 200 km/h.

### CARE INSTRUCTIONS

Only use mild detergent solutions for cleaning, or even better: just water. Never use solvents or solvent-containing liquids for cleaning. When outdoor temperatures are high, it is recommended to clean the sign every two days, when they are moderate or low, once a week. Magnetic signs have to be removed from the vehicle before each cleaning (manual or automatic carwash).

**When used on metallic or new lacquer coats, both the magnetic sign and the substrate are to be cleaned on a daily basis and kept dry.**

### STORAGE INSTRUCTIONS

The magnetic sign should be stored in a flat position. If the sign has to be rolled up temporarily, make sure the magnetic side faces inward and the roll's diameter measures at least 10cm. Even as our Magnetoflex® material is buckling-resistant, it is advisable to treat the sign carefully and avoid unnecessary bending.

### GENERAL INFORMATION

The magnetic side of the sign is sealed with a protective layer. When outdoor temperatures are high or very high, or if the magnetic sign is in constant use on the vehicle's body for several days in a row, condensation occurs underneath the sign. This may cause the sign's magnetic backing to bond with the car's paint. To avoid such damages, keep the magnetic sign off the car overnight or when marking the vehicle is not necessary. During the day, it is recommended to lift the magnetic sign off the car at least once.

When outdoor temperatures are moderate or low, remove the magnetic sign every three days. Generally, we recommend placing the magnetic sign on the car only when you actually need to mark your car. At all other times, you should remove the magnetic sign and store it properly.

The magnetic effect decreases significantly if a car's body has been primed or painted (or smoothed) several times in a row.

Cracks and fractures in the magnetic sheet only occur due to inappropriate use. According to the manufacturer, the magnetic material works properly only at temperatures between -20° C and +50° C.